
domogik-plugin-nutserve

Release 0.1

January 30, 2017

1	Plugin documentation	1
1.1	Last change	1
1.2	Purpose	1
1.3	Plugin configuration	1
2	Development informations	3
2.1	How it UPS status found ?	3
2.2	xPL messages	3
2.3	NUT driver compatibility	3
3	Changelog	9
3.1	0.2.0	9
3.2	0.1a	9

Plugin documentation



1.1 Last change

New instructions to apply changes from immediatly previous version.

- **0.2.0** [(11-12-2016) First published version for domogik 0.5]
 - Version without xpl, work with 0MQ
 - Update device_type, recreate domogik device with them.
- Previous change

1.2 Purpose

This Domogik plugin monitor UPS (Uninterruptible Power Supplies) through communicat with NUT project server.

Create a socket connection with NUT to get UPS informations and report them to domogik sensors.

You must configure as your needs the NUT library and give parameters connection at plugin.

UPS Status, on mains (on line), on battery, connected, lost connection,... are send to domogik device.

Sensors values for input, output, battery voltage and battery charge are also send to domogik device.

1.3 Plugin configuration

1.3.1 Configuration

In Domogik administration section, go to client plugin-nutserve details page.

Key	Default value	Description
startup-plugin	false	Automatically start plugin at Domogik startup
Ip nut server	localhost	Set host NUT server.
Port nut server	3493	Set NUT server port number.
Login		Set NUT user login.
Password		Set NUT user password.

1.3.2 Creating devices for UPS Client

In clients page of admin UI, go to **plugin-nutserve-<your_host_domogik>**, select tab “Devices”, “New” to create your devices.

Chose one way creation by product or instance type.

Instance-type : ups.device

Key	Example	Description
Device	My_UPS	The display name for this device.
Description	What you want	A short descriptionn for this device.
Global device	My_UPS	Same name of UPS name in ups.conf file.
timer_status	60	Timer (seconds) for poll UPS status <ul style="list-style-type: none">• “0”: desactivat polling. Status is sended to domogik only if changed.
	3	Timer (seconds) for poll UPS values <ul style="list-style-type: none">• “0”: desactivat polling. Values are sended to domogik only if changed.

Global —— – **Global**

timer_poll

Development informations

2.1 How it UPS status found ?

The plugin just use the NUT server functions.

2.2 xPL messages

No xPL message handle, use only 0MQ

2.3 NUT driver compatibility

Plugin need driver device class for working with specific UPS.

2.3.1 Existing drivers device.

- **Basic:** Must work with any NUT driver but handle only status and events onmains, onbattery, batterylow, comm_ok and comm_lost If NUT server return battery.charge driver can handle it.
- **Blazer_USB:** Handle all basic and if available by NUT server:

battery.charge calculat, input-output voltage status , input frequence status, output current status and temperature status

2.3.2 Add development NUT driver compatibility

Plugin offer simple way to add new driver device.

File lib/nutdevices.py contains a DeviceBase python class who handle basic methodes. You create a new class inherit this base class and overwriting some methodes to get NUT driver compatibility. You just have to add new driver device class reference in createDevice methode.

```
def createDevice(data):  
    """ Create a device depending of 'driver.name' given by data dict.  
        - Developer : add your python class derived from DeviceBase class. """  
    if data.has_key('driver.name') :
```

```
if data['driver.name'] == 'blazer_usb' : return Blazer_USB(data)
    # Just add next line
elif data['driver.name'] == 'My_new_driver' : return My_New_Device(data)
else : return DeviceBase(data)
else : return DeviceBase(data)
```

Have a look to Network UPS Tools and get details informations on Driver section of [User manual pages](#)

Getting UPS variables available

- Use clients commands **upsc** of Network UPS Tools to get all variables available : Example :

```
$ /bin/upsc MyUPS@localhost
battery.voltage.nominal: 12.0
battery.voltage: 13.60
beeper.status: enabled
device.type: ups
driver.version.internal: 0.04
driver.name: blazer_usb
driver.version: 2.6.3
driver.parameter.pollinterval: 2
driver.parameter.port: /dev/upsZ3
driver.parameter.productid: 5161
driver.parameter.vendorid: 0665
input.voltage.nominal: 230
input.voltage.fault: 240.2
input.voltage: 240.2
input.current.nominal: 2.0
input.frequency.nominal: 50
input.frequency: 49.9
output.voltage: 240.2
ups.type: offline
ups.vendorid: 0665
ups.delay.shutdown: 30
ups.productid: 5161
ups.delay.start: 180
ups.status: OL
```

- Or using plugin tools **lib/nutsockclient.py** : Simple set your own parameters on **__main__** section of lib/nutsockclient.py file.

```
if __name__ == "__main__":
    # Set upsaddr, upsport and upsname depending on your config
    upsaddr = <UPS server IP>
    upsport = <UPS server port (generaly= 3493)>
    upsname = <UPS name>
```

Run python file “lib/nutsockclient.py“ and you get appropriate informations.

```
$ python nutsockclient.py
+++ Internal NUTSocketClient created ***
Client connected to Z3_SERVER

*** getNUTVersion
{'cmd': 'VER', 'data': '2.6.3', 'error': ''}

*** getNUTNetworkVersion
{'cmd': 'NETVER', 'error': 'NUT version to old (2.6.3), NETVER function not handle, Update NUT'}
```

```

*** getNUTHelp
Commands: HELP VER GET LIST SET INSTCMD LOGIN LOGOUT USERNAME PASSWORD STARTTLS

{}

*** getUPSList
{'cmd': 'LIST UPS', 'data': {'Z3_SERVER': 'Server Linux Internet'}, 'error': ''}

*** getUPSVars
{'cmd': 'LIST VAR',
 'data': {
     'input.voltage.nominal': '230', 'beeper.status': 'enabled', 'input.voltage.fault': '',
     'driver.version.internal': '0.04', 'input.voltage': '238.4', 'ups.type': 'offline',
     'ups.vendorid': '0665', 'driver.name': 'blazer_usb', 'ups.delay.shutdown': '30', 'ou',
     'ups.productid': '5161', 'ups.delay.start': '180', 'driver.version': '2.6.3', 'inpu',
     'battery.voltage.nominal': '12.0', 'driver.parameter.pollinterval': '2', 'driver.par',
     'battery.voltage': '13.60', 'driver.parameter.productid': '5161', 'ups.status': 'OL',
     'driver.parameter.vendorid': '0665'
   },
 'ups': 'Z3_SERVER', 'error': ''}

*** getUPSRWVars
{'cmd': 'LIST RW', 'data': {}, 'ups': 'Z3_SERVER', 'error': ''}

*** getUPSCmds
{'cmd': 'LIST CMD',
 'data': [
     'beeper.toggle', 'load.off', 'load.on', 'shutdown.return', 'shutdown.stayoff', 'shutd
     'test.battery.start', 'test.battery.start.deep', 'test.battery.start.quick', 'test.b
   ],
 'ups': 'Z3_SERVER', 'error': ''}

*** getUPSListClients
{'cmd': 'LIST CLIENT', 'error': 'NUT version too old (2.6.3), LIST CLIENT function not handle'}
```

```

*** getUPSVar
{'var': 'ups.status', 'cmd': 'GET VAR', 'ups': 'Z3_SERVER', 'value': 'OL', 'error': ''}

*** getUPSNumLogin
{'cmd': 'NUMLOGINS', 'data': '2', 'error': ''}
Terminated
--- Internal NUTSocketClient deleted ---
```

Creating new Driver device class

- File lib/nutdevices.py contains a DeviceBase python class who handle basic methodes. You create a new class inherit this base class and overwriting some methodes to get acces of this new service or hardware.

You can insert your new class in the file or create a new with import DeviceBase :

```
class My_New_Device(DeviceBase): # simply new class declaration
    def checkInputVoltage(self): # overwrite methodes class
        ....
```

Data format who must be return by methods

By calling source class method `self.checkStatus()` you get `DATA_TYPE_RETURN` value.
`DATA_TYPE_RETURN` is a dict type with keys.

```
DATA_TYPE_RETURN :  
{  
    'Modify' : True/False, # if the value change you must set to True.  
    'sensorsData' : { # Here all value who must transmit to domogik.  
        'status' : <'mains' or 'battery', or 'unknown'>  
        'event' : <All event define in UPS_Events>  
    }  
}
```

Use `self.handleUPS_Events` to set UPS_Events status at True/False.

This method :

- Return a tuple with a boolean and a string for event key of `DATA_TYPE_RETURN`.
- Manage an UPS_Event retention for some UPS Events values.
- Ret others depending UPS_Events status of new event, Ex:

```
if input_voltage_low' set to True  
    'input_voltage_high' must set to False  
    'input_voltage_ok' must set to False
```

How to use it :

```
....  
retval = self.checkStatus()  
retVal['modify'], retVal['sensorsData']['event'] = self.handleUPS_Events(< an UPS_Events>, True/
```

Dependency UPS_Events status

UPS_Events are groups in dependencies status, if an item change others items must change. Developer has no need to handle dependencies, `self.handleUPS_Events` method handle them. It's just for information.

- **On line status:** ‘onmains’ => The UPS has begun operating on mains power
 - ‘onbattery’ => The UPS has begun operating on battery power
- **Battery status:** ‘battlow’ => The UPS battery is low
 - ‘battfull’ => The UPS battery is fully charged
- **Battery test status:** ‘bti’ => Battery test initiated
 - ‘btp’ => Battery Test Passed
 - ‘btf’ => Battery Test Failed
- **UPS server communication status:** ‘comms_lost’ => The host has lost communication with the UPS
 - ‘comms_ok’ => Communication with the UPS has been restored
- **Input frequency status:** ‘input_freq_error’ => The input frequency is out of range
 - ‘input_freq_ok’ => The input frequency has returned from an error condition

- **Input voltage status:** ‘input_voltage_high’ => The input voltage is too high
‘input_voltage_low’ => The input voltage is too low
‘input_voltage_ok’ => The input voltage is OK following a previously “too low” or “too high” state
- **Output voltage status:** ‘output_voltage_high’ => The UPS output voltage is too high
‘output_voltage_low’ => THe UPS output voltage is too low
‘output_voltage_ok’ => The UPS output voltage has returned to normal following a “too high” or “too low” condition.
- **Output status:** ‘output_overload’ => The UPS output is in overload
‘output_ok’ => The UPS output has returned from overload
- **Temperature status:** ‘temp_high’ => The UPS temperature is too high
‘temp_ok’ => The UPS temperature has returned from an over-temperature condition

Overwrited methods

- **getBatteryCharge:** You can overwrite this method but it is essential to call source method at first, Because if NUT server has is own level it's probably the better.

Overwriting structure:

```
def getBatteryCharge(self):
    charge = DeviceBase.getBatteryCharge(self)
    if charge: return charge
    #.... Your new code in case of none 'battery.charge' handle by NUT server ....
    return charge # type float
```

- **checkAll:** Check All UPS stuff and return they values in DATA_TYPE_RETURN list.

This method work with DeviceBase class, overwrite it only if new check method is necessary.

You can overwrite this method but it is essential to call source method at first.

Overwriting structure:

```
def checkAll(self):
    data = DeviceBase.checkAll(self)
    data = data.append(self.Your_New_Check())
    ....
    return data
```

- **checkInputVoltage:** Source method do nothing and return None. You must overwrite it with status calculate to return event input_voltage_low, input_voltage_high, input_voltage_ok in format DATA_TYPE_RETURN

Overwriting example:

```
def checkInputVoltage(self):
    # Check if key exist in UPS vars
    if self._vars.has_key('input.voltage.nominal') :
        # Calculat range voltage status
        high = self._vars['input.voltage.nominal'] * 1.06
        low = self._vars['input.voltage.nominal'] * 0.94
    else : # Return None to report not handling UPS event
        return None
    # Check if key exist in UPS vars
```

```
if self._vars.has_key('input.voltage') :
    # Get UPS status in DATA_TYPE_RETURN format
    retVal = self.checkStatus()
    # Test voltage status
    if self._vars['input.voltage'] >= high :
        # Set 'Modify' and UPS_Events DATA_TYPE_RETURN format
        retVal['modify'], retVal['sensorsData']['event'] = self.handleUPS_Events('input_volt_high')
    elif self._vars['input.voltage'] <= low :
        # Set 'Modify' and UPS_Events DATA_TYPE_RETURN format
        retVal['modify'], retVal['sensorsData']['event'] = self.handleUPS_Events('input_volt_low')
    else :
        # Set 'Modify' and UPS_Events DATA_TYPE_RETURN format
        retVal['modify'], retVal['sensorsData']['event'] = self.handleUPS_Events('input_volt_norm')
return retVal # Return DATA_TYPE_RETURN format
return None # Return None to report not handling UPS event
```

- **checkInputFreq:** Source method do nothing and return None. You must overwrite it with status calculate to return event input_freq_error, input_freq_ok in format DATA_TYPE_RETURN

Overwriting structure : same principle than checkInputVoltage

- **checkOutputVoltage:** Source method do nothing and return None. You must overwrite it with status calculate to return event output_voltage_low, output_voltage_high, output_voltage_ok in format DATA_TYPE_RETURN

Overwriting structure : same principle than checkInputVoltage

- **checkOutput:** Source method do nothing and return None. You must overwrite it with status calculate to return event output_overload, output_ok in format DATA_TYPE_RETURN

Overwriting structure : same principle than checkInputVoltage

- **checkTemperature:** Source method do nothing and return None. You must overwrite it with status calculate to return event temp_high, temp_ok in format DATA_TYPE_RETURN

Overwriting structure : same principle than checkInputVoltage

Changelog

3.1 0.2.0

- domogik 0.5 upgrade
- Version without xpl, work with 0MQ
- Update device_type, recreate domogik device with them.
- Add timer pool control as device parameter.
- Live domogik device create/update, no need to restart plugin
- Update user and developer doc.

3.2 0.1a

- Plugin creation